

## VULCAN-VULCAP Mold Filler Pads

### BEAD FILLER PADS

Used to Protect Airbag and Bead Area of Heatpad

<u>MODEL</u>	<u>PART #</u>	SHIP WT.		
		<u>lbs</u>	<u>kg</u>	
RTV12	12100	4	1.8	Pair
MPB	904600	4	1.8	Pair
V14	201500	6	2.7	Pair
SM180/SM250/MV20	830080	10	4.5	Pair
V21/V310/MV30	210200	48	21.8	Pair
V37.5/MV40/MV50	373100	78	35.4	Pair

### SIDE FILLER PADS

Used to Protect Toe of Heatpad when Curing Narrow Tires

<u>MODEL</u>	<u>PART #</u>	SHIP WT.		
		<u>lbs</u>	<u>kg</u>	
MPB	904700	7	3.2	
V14/SM180/SM250/MV20	810600	9	4.1	
V21/V310/MV30	216260	35	15.9	
V33/V37.5/MV40	373260	60	27.2	
V45/MV50	500500	85	38.5	

### BOTTOM FILLER PADS

Used to Raise Small Tire to clear Cross Clamp

<u>MODEL</u>	<u>PART #</u>	SHIP WT.		
		<u>lbs</u>	<u>kg</u>	
V14/SM180/SM250/MV20	830070	29	13.2	
V21/V310	210090	54	24.5	
V33/V37.5	373830	85	38.5	
V45	500600	125	56.7	