

VULCAN-VULCAP VRC Control Panel and Clamp Replacement Parts

<u>PART #</u>	<u>DESCRIPTION</u>	<u>SHIP WT.</u>	
		<u>lbs</u>	<u>kg</u>
PLATES			
1003099	Plates 6" x 9" Outside	8	3.6
1003109	Plates 8" x 8" Inside	6	2.7
1003119	Plates 8" x 8" Outside	7	3.2
1003129	Plates 12" x 12" Inside	12	5.5
1003139	Plates 12" x 12" Outside	16	7.3
1003149	Plates 12" x 12" Inside Shoulder	12	5.5
1003159	Plates 12" x 14" Shoulder	17	7.7
1003169	Plates 14" x 14" Inside	33	15
1003179	Plates 14" x 14" Outside	32	14.5
1003189	Plates 14" x 16" Shoulder	34	15.5
1003199	Plates 10" x 20" Inside C/W Adpt.	32	14.5
1003209	Plates 10" x 20" Outside C/W Adpt.	38	17.3
1003219	Plates 20" Round Inside	32	14.5
1003229	Plates 20" Round Outside	30	13.6

CLAMP REPL. PARTS			
1003306	Pinion and Key		
1003313	Gear Spacer		
1003305	Gear		
1003312	T-Lock Screw		
1003304	Chain Gear Lock		
1003337	Air Regulator		
1003351	Air Valve		
1003326	Air Gauge		
1003328	Safety Valve		
1003327	Pilot Light		
1003322	5 hr Timer		
1003323	12 hr Timer		
1003325	Ampmeter		

NATIONAL Heat Pads & Airbags

<u>MODEL</u>	<u>PART #</u>		<u>SHIP WT.</u>	
			<u>lbs</u>	<u>kg</u>
100-A4AST – 18-4 Airbag	69-113	18-1/2" x 12" (47 cm L x 30 cm W)	6	2.7
100-A4AST – 29-4 Heat Pad, 110V	69-114	8" x 18"	4	1.8
100-A4AST – 29-4 Heat Pad, 220V	69-115	8" x 18"	4	1.8
400-AST – H21 Truck Heat Pad, 110V	69-988		30	13.6
400-AST – H21 Truck Heat Pad 220V	69-989		30	13.6
400-AST – P21 Truck Airbag	69-990		40	18.0
400-AST – P24 Spreader Bag	69-991	12" x 15-3/4" (30 cm L x 40 cm W)	6	2.7